

## Overview

Adoption of low power design techniques is growing rapidly to enable ASICs and SoCs to support the advanced power management required across today's electronic products, from mobile devices to servers and networking. Advanced low power techniques such as Power Gating, Retention, Low-VDD Standby, and Dynamic Voltage Scaling (DVS) employ voltage control to enable fine-grained power management.

